



## Recording Frame Rate Setup on Silverline JPEG2000 DVR's




Enter the main menu by pressing the 'Menu' button on the front of the unit and inputting your password.

Use the down arrow to navigate to 'Record Setup' and press 'Enter'.



Press the 'Enter' button on the front of the DVR to enter the 'Record Configuration' menu.



At the bottom of the screen there are the 3 options for recording. Choose which method of recording you are using and change the interval (1/1X as default) to the appropriate number for the installation using the 'Plus' button on the front of the unit.

To find out the frame rate of the interval simply divide 100 (50 for the 4 channel unit) by the second number on the interval.

E.g. Continuous record at 1/20X is  $100/20=5$  (frames per second).